

RAT BLOCKER FITTING INSTRUCTIONS

Fitting inside a standard inspection manhole

Screw the mounting pole into the rat guard and lower into the manhole. Slide the rat blocker into the sewer pipe until the stopper is reached. Unscrew the mounting pole.

You can also slide the rat stopper manually (without the mounting pole) into the sewer pipe until the stopper is reached.



Fitting into a conical well:

Attach the telescopic arm (accessory) and complete the procedure described above.



If (due to sediments, etc.) the rat blocker does not slide easily into the sewer pipe, the sides can be compressed gradually (using some force or tools) until it fits inside the sewer pipe.